

TELEPHONE EQUIPMENT



Desk Phones

Illustrations 1 through 4 show wall receptacles (standard jacks) which can accommodate modular telephone cords. To install your phone, match the plug at the end of the telephone cord with the receptacle and insert. To disconnect the phone, squeeze the clip on the plug and pull out of the receptacle.

Adapters

Illustrations 5 and 6 show receptacles (non-standard jacks) which can be made to accommodate modular telephone cords by the use of adapters. The adapters simply plug into the receptacle. With the adapter in place, follow the above steps to install your phone.

Wall Phones

A receptacle for a wall mounted telephone is shown in illustration 7. To connect your wall phone, match the holes in the back of the telephone with the rivets on the wall mounting and push the telephone lightly against the mounting while sliding it down into place over the rivets. To disconnect, slide the telephone up to lift it off the rivets. Then pull the phone away from the receptacle.

The illustrations below should be helpful to you when installing or disconnecting your telephones. Other types of modular jacks may also be encountered.

